



## 10 - Valves on element

Ref	Part Number	Qty	Name
		2	VALVES ON ELEM.
1005	• <del>1614 8980 00</del>	1	VALVE HOUSING
	🔄 Substituted by:	1614 8980 01	- HOUSING VALVE (quantity: 1)
1010	• 1614 8976 00	1	PLUG
1015	• <del>0661 1000 30</del>	1	SEAL CARTRIDGE
	🔄 Substituted by:	0661 1000 44	- SEAL WASHER (quantity: 1)
1015	•	1	SEAL
	🛠️ Service kits:	2906 0693 00	- OIS280KW CHECK VALVE KIT
1020	•	1	SPRING
	🛠️ Service kits:	2906 0693 00	- OIS280KW CHECK VALVE KIT
1025	•	1	CHECK VALVE
	🛠️ Service kits:	2906 0693 00	- OIS280KW CHECK VALVE KIT
1030	• 1614 8974 00	1	PISTON
1035	• <del>1623 4597 00</del>	1	VALVE OIL STOP
	🔄 Substituted by:	1635 5776 00	- VALVE OIL STOP (quantity: 1)
1035	•	1	VALVE OIL STOP
	🔄 Substituted by:	1635 5776 00	- VALVE OIL STOP (quantity: 1)
	🛠️ Service kits:	2906 0694 00	- OIS280KW OIL STOP VALVE KIT
1045	•	1	SPRING
	🛠️ Service kits:	2906 0694 00	- OIS280KW OIL STOP VALVE KIT
1050	• 1614 8972 00	1	COVER
1055	•	1	O-RING
	🛠️ Service kits:	2906 0694 00	- OIS280KW OIL STOP VALVE KIT
1060	• 0147 1363 03	4	SCREW HEXAGON
1065	• 1614 8975 00	1	FLANGE
1070	•	1	O-RING
	🛠️ Service kits:	2906 0694 00	- OIS280KW OIL STOP VALVE KIT
1075	• 0147 1363 03	4	SCREW HEXAGON
1080	• 0301 2344 00	4	WASHER PLAIN
1085	•	1	O-RING
	🛠️ Service kits:	2906 0775 00	- GA315-500W LH ELMT INSTALL KIT
		2906 0693 00	- OIS280KW CHECK VALVE KIT
		2906 0774 00	- GA315-500W RH ELMT INSTALL KIT
1090	•	1	O-RING
	🛠️ Service kits:	2906 0775 00	- GA315-500W LH ELMT INSTALL KIT
		2906 0693 00	- OIS280KW CHECK VALVE KIT
		2906 0774 00	- GA315-500W RH ELMT INSTALL KIT
1095	•	3	O-RING
	🛠️ Service kits:	2906 0775 00	- GA315-500W LH ELMT INSTALL KIT
		2906 0693 00	- OIS280KW CHECK VALVE KIT
		2906 0774 00	- GA315-500W RH ELMT INSTALL KIT
1100	• 0211 1960 28	6	CAP SCREW
1105	• 0686 3716 01	2	PLUG 1/4 A A
1110	• <del>0661 1000 25</del>	2	SEAL WASHER 13.74 X 20.57 X 2
	🔄 Substituted by:	0661 1000 38	- SEAL WASHER DOWTY 1/4" (quantity: 1)
1110	• 0661 1000 38	2	SEAL WASHER DOWTY 1/4"