

Operating instructions






1. General

1.1 General user information

The regulations applicable to the place of installation are to be observed before the commissioning and during the operation of the product from **sera**.

Always read these instructions and particularly the safety instructions before installation and commissioning of the **sera** product.

1.2 Symbols and notes used in these operating instructions

Notes (Text and symbol)	Danger type			Meaning (in the operating instructions)
	Danger to life	Risk of injury	Dam. to property	
DANGER! 	X	X	X	Identifies imminent danger that could lead to death or serious injury if not avoided.
WARNING! 	X	X	X	Indicates a potentially dangerous situation that could lead to death or serious injury and damage to property if not avoided.
CAUTION! 		X	X	Indicates a potentially dangerous situation that could lead to slight or minor injury or damage to property if not avoided.
ATTENTION! 			X	Indicates a potentially dangerous situation that could lead to damage to property if not avoided.
NOTE! 				Indicates information which help to facilitate the work and is useful for a trouble-free operation.

Operating instructions

1.3 Quality instructions

Observance of these operating instructions and, in particular, the safety instructions, helps to

- avoid dangers to persons, machines and environment,
- increase reliability and service life of the product and the complete system,
- reduce repair cost and downtime.

The **sera** quality management and quality assurance system for pumps, systems, valves and fittings and compressors is certified according to ISO 9001:2008.

The **sera** products meet the valid safety and accident prevention regulations.



ATTENTION!

Always keep these operating instructions within reach at the place of installation.



WARNING!

Pay attention to the safety data sheet of the medium! The owner must take corresponding accident prevention measures to protect operating personnel from danger through the delivery media used!

2. Safety instructions

2.1 Personnel qualification and training

The personnel for operation, maintenance, inspection and installation must be suitably qualified for their tasks. The owner must clearly define responsibility and supervision of the personnel.

If the personnel do not have the knowledge required, then personnel is to be trained and instructed correspondingly. Such training can be provided by the manufacturer / supplier upon order of the owner. In addition, the owner has to ensure that personnel have understood the operating instructions completely.

2.2 Dangers in case of inobservance of the safety instructions

Inobservance of these safety instructions can result in danger to persons, hazards to the environment and damage to the product.

Inobservance of the safety instructions may lead to:

- Failure of important functions of the product/system.
- Inobservance of prescribed methods for maintenance and servicing.
- Danger to persons through chemical influences.
- Hazards to the environment through leaking dangerous media.

2.3 Safety conscious working

The safety instructions specified in this operating manual, the national regulations for accident prevention, the safety regulations for the pumped medium valid at the place of installation as well as internal working-, operating-, and safety instructions of the owner are to be observed.

2.4 Safety instructions for owner / operator

Leaking hazardous delivery media supplies are to be disposed off in such a way that any danger to persons and the environment is excluded. The legal regulations are to be observed.

Operating instructions

2.5 Safety instructions for maintenance, servicing and installation work

The owner must ensure that any maintenance-, servicing- and installation work is only entrusted to authorized and suitably qualified personnel who have carefully read and understood the operating instructions.

Only those spare parts are to be used which meet the requirements of the specified operating conditions.

Threaded joints and connections may only be disconnected when the system is not under pressure.

2.6 Arbitrary modification and production of spare parts

Modifications of or changes to the product are only permitted after previous agreement of the manufacturer. Original spare parts and accessories which were approved by the manufacturer are essential for safety reasons.



CAUTION!

If the product is modified without authorization of the manufacturer or spare parts are used which are not approved, any warranty claim becomes null and void.

2.7 Improper operations

Operating safety of the supplied product is only guaranteed if the product is used as intended, according to the descriptions in Chapter „Intended use“ of these operating instructions.

2.8 Intended use

The **sera** product is only to be deployed according to the intended purpose stated in the product description. If the product is to be used for other applications, then the suitability of the suction lance for the new operating conditions must be discussed with **sera** beforehand!

Criteria for operation of the product in accordance with the intended use:

- Observe characteristics of the medium (please see safety- and product data sheet of the delivery medium – the safety data sheet is to be provided by the supplier / owner of the pumped medium).
- Resistance of the materials which come into contact with the pumped medium.
- Operating conditions at the place of installation.
- Temperature of the pumped medium.
- Max. pressure of the product.

2.9 Personal protection for maintenance and service


National safety regulations for the pumped medium must strictly be adhered to.

In case of accidents check whether the following substances are emitted:

- Leaking fluids.
- Leaking vapours.

Emissions are to be monitored by corresponding control systems of the total installation.

Operating instructions




Wear protective clothing, gloves, breathing mask and a face protecting mask.





ATTENTION!



Personal protective equipment must be provided by the owner!

NOTE!









NOTE!

3. Transport and storage

3.1 General

sera - products are checked for perfect condition and function previous to shipment. Check for transport damage immediately after arrival of goods. If damage is found, this is to be reported immediately to the responsible carrier and the manufacturer.



The packaging material must be disposed of appropriately!

NOTE!

3.2 Storage

An undamaged packaging protects the unit during storage and should only be opened when the product is installed.

Proper storage increases the service life of the product and includes prevention of negative influences such as heat, moisture, dust, chemicals etc.

The following storage specifications are to be observed:

- Storage place: cool, dry, dustfree and slightly ventilated
- Storage temperature between +2°C and +40°C
- Relative air humidity not more than 50 %.
- The maximum storage time is 12 months.

If these values are exceeded, metal products should be sealed in foil and protected from condensation water with a suitable desiccant.

Do not store solvents, fuels, lubricants, chemicals, acids, disinfectants and similar in the storage room.

Operating instructions

4. Product description


sera check valve prevents that the medium flows back.



The check valves are not applicable as absolutely tightly closing shut-off fittings!

NOTE!

Symbol	661.2 ... 663.2
--------	-----------------



4.1 Temperature range

The temperature range of the check valves is between 0°C und +40°C (in relation to water).

The temperature range changes depending on the medium ► this must be checked by the owner.

Operating instructions

5. Technical data


Type	Nominal width DN	Max. admissible operating pressure ¹⁾		Max. flow rate bis l/h	Max. pump stroke capacity cm ³	Opening pressure		
		bar plastic	bar steel			PVC-U	bar PP-FRP PVDF-FRP	1.4571
661.2	8	10	63	200	20	0,2	■ 0,5 ■ 1,5	0,2
662.2	15	---	40	600	100	---	---	0,2
663.2	20	10	25	1100	190	---	■ 0,5 ■ 1,5	0,2

¹⁾ for 20°C (water)

Materials				
Type	Housing	Seal	Valve ball	Spring
661.2	PVC-U	■ FPM ■ EPDM ■ FEP-umm.	■ Glas ■ PTFE ■ 1.4401	2.4610 (Hastelloy C4)
661.2 663.2	PP-GFK PVDF-GFK	■ FPM ■ EPDM ■ FPM-umm.	■ Glas ■ PTFE ■ 1.4401	2.4610 (Hastelloy C4)
661.2 662.2 663.2	1.4571	■ FPM ■ EPDM ■ FPM-umm.	■ PTFE ■ 1.4401	2.4610 (Hastelloy C4)

Operating instructions

5.1 Dimensions



Materials	Type	DN	GA Outlet	GE Inlet	L	D		t	SW
						mm			
■ PVC-U	661.2	8	G3/4	G3/4	60	27		13	---
■ PP-FRP	661.2	8	G3/4	G3/4	65	---		18	30
	663.2	20	G1 1/4	G1 1/4	60	---		25	46
■ PVDF-FRP	661.2	8	G3/4	G3/4	65	---		18	30
	663.2	20	G1 1/4	G1 1/4	60	---		24	46
■ 1.4571	661.2	8	G3/4	G3/4	60	---		13	27
	662.2	15	G1	G1	104	---		17	41
	663.2	20	G1 1/4	G1 1/4	119	---		20	50

Operating instructions

6. Installation

- The check valves are installed in the pressure line (1).
- The installation / operating position is vertical.
- Flow direction is marked with an arrow (2) .

Example of installation:



7. Decommissioning

The following points must be observed when you decommission:

- Switch off the unit.
- Disconnect the unit from the power supply.
- Empty the product.



DANGER!

After the chemical was drained, rinse the unit / product with water or a suitable medium until there are no more chemical residues!
Note the compatibility of the rinsing medium with the chemical according to the safety data sheet.

Exothermic reactions must be avoided by all means!

8. Disposal

- Shut-down the product. Please see "Decommissioning".

8.1 Dismantling and transport

- Package the suction lance and ship.



NOTE!

A clearance certificate must be filled in when systems are returned to the manufacturer (see Chapter „Clearance certificate“).

Acceptance will be rejected if this clearance certificate is not attached.